

Подходящие модели пылесосов SAMSUNG

VC15K4116V1/UK
VC15K4116VR/EV
VC15K4136VL/EV
VC15K4136VL/UK
VC15K4176VP/EV
VC15M2110SB/EV
VC15M2130SG/EV
VC15M21A0SR/EV
VC15M21B0SN/EV
VC15M251AWB/EV
VC15M255AWR/EV
VC15M3120VB/EV
VC15M3140V1/EV
VC18KBCNKD
VC18KMPNKD
VC18M2110SB/EV
VC18M2110SP/EV
VC18M2110SP/UK
VC18M2130SR/EV
VC18M2150SG/AD
VC18M2150SG/EV
VC18M2150SG/UK
VC18M2150SN/EV
VC18M21A0S1/EV
VC18M21A0S1/UK

VC18M21A0SB/EV
VC18M21A0SB/UK
VC18M21B0S2/EV
VC18M21C0CN/EV
VC18M21C0CN/UZ
VC18M21C0CN/W4
VC18M21C0CR/EV
VC18M21C0CR/UZ
VC18M21C0CR/W4
VC18M21C0VN/EV
VC18M21C0VN/UK
VC18M21C0VR/EV
VC18M21C0VR/UK
VC18M21D0CG/EV
VC18M21D0CG/UZ
VC18M21D0CG/W4
VC18M21D0VG/EV
VC18M21D0VG/UK
VC18M21N9VD/AD
VC18M21N9VD/EV
VC18M21N9VD/UK
VC18M3120V1/EV
VC18M3120V1/UK
VC18M3120VB/EV
VC18M3120VB/UK

VC18M3120VU/EV
VC18M3120VU/UK
VC18M3125V1/UZ
VC18M3125VB/UZ
VC18M3125VU/UZ
VC18M3125XB/DZ
VC18M3125XP/DZ
VC18M3140VN/EV
VC18M3160VG/EV
VC18M3160VG/ME
VC18M3160VG/UK
VC18M3179VD/AD
VC20F30WDHL/EV
VC20F30WDHL/UK
VC20F30WNFN/EV
VC20F30WNGR/EV
VC20M251AWB/EV
VC20M251AWB/UK
VC20M253AWR/EV
VC20M253BWR/UZ
VC20M255ACB/EV
VC20M255ACB/UZ
VC20M255ACB/W4
VC20M255AWB/EV
VC20M255AWB/UK

VC20M255AWN/EV
VC20M255BWB/UZ
VC20M257ACR/EV
VC20M257ACR/UZ
VC20M257ACR/W4
VC20M257AWR/AD
VC20M257AWR/EV
VC20M257AWR/UK
VC20M257BWR/UZ
VC21K5136VB/EV
VC24JVNJGBJ/EV
VC24KVNJGRL/EV
VC24LVNJGBB/EV
VC33M2110L2
VC33M2110LB
VC33M2110LP
VC33M2110LR
VC33M2130LB
VC33M2130LR
VC33M21A0L1
VC33M21A0L2
VC33M21A0LG
VC33M21A0LN
VC44M21C0L1
VC44M21C0LN